

INSTALLAZIONE:

L'installazione del controller lambda è estremamente semplice:

- Alimentare il controller con una alimentazione sottochiave (nero=massa, rosso=12V)
- Connettere il sensore lambda
- Connettere il connettore di segnale al cablaggio del Chrome o della Dasy

SETTAGGI:

Il controller lambda fornisce un'uscita lineare. Impostare sul cruscotto Chrome o sulla Dasy i seguenti valori per il canale a cui è connesso il controller:

- Valore minimo 8 (0.549 se si vuole avere i valori in lambda)
- Valore massimo 22 (1.51 se si vogliono avere i valori in lambda)

INSTALLATION:

The installation of the lambda controller is very easy:

- Connect the controller to a 12 under key (black= ground, red= 12V)
- Connect the lambda sensor
- Connect the signal connector to the Chrome's or Dasy's wiring

SETTINGS:

The lambda controller gives a linear output in the 0-5V range. Set on Chrome or Dasy these values for the analog channel:

- Minimum value 8 (0.549 if you want the values in lambda)
- Maximum value 22 (1.51 if you want the values in lambda)

Connettore/Connector

Marrone/Brown : Segnale/Signal

Blu/Blue: Massa/ground

